

HOW TO HANG YOUR WAVE CURTAINS

HANGING YOUR WAVE CURTAINS

The wave cord (6 cm or 8 cm) is supplied to the correct length on the cord holder. The number of runners corresponds to the number of hooks in the curtain. Count the twin hooks fitted at both ends of the wave curtain as one runner each. You should always end up with an even number of runners.



FIT THE RUNNERS

Fit the first and last runner of the wave cord onto the end runner. Make sure the eye on the underside of the end runner is facing downwards, then click the runner into the pre-shaped opening from above.



SLIDE THE END RUNNER ONTO THE TRACK

Slide the first end runner onto the curtain track, followed by the end stop with screw. Make sure the flat side of the end runner is facing outwards.

Then slide all the runners of the wave cord onto the track, followed by the second end runner. Again, make sure the flat side of the end runner is facing outwards.



FIT THE TWIN HOOKS

Insert the twin hooks into the end runner so that the final wave of the curtain runs evenly in line with the back of the wave. If necessary, shorten the end runner by snapping off the square sections to the required length.



HOOK THE CURTAIN ONTO THE RUNNERS

Hang the wave curtain by inserting all the hooks into the runners.



SHAPE THE CURTAIN

Arrange the curtain fabric so that the waves are evenly formed. Finally, slide the wave curtain towards the corner and secure the end stop with the screw so that the curtain stays in place when opening and closing.



ALLOW THE CURTAINS TO SETTLE

Use a handheld steamer, or alternatively a steam iron, to remove any remaining creases from the curtain.

Leave the curtains hanging for a few days to allow the fabric to settle and achieve the best result.